

# Anybus<sup>®</sup> Wireless Bolt<sup>™</sup>

### **STARTUP GUIDE**

SP2139 3.0 en-US ENGLISH





# **Important User Information**

### Disclaimer

The information in this document is for informational purposes only. Please inform HMS Networks of any inaccuracies or omissions found in this document. HMS Networks disclaims any responsibility or liability for any errors that may appear in this document.

HMS Networks reserves the right to modify its products in line with its policy of continuous product development. The information in this document shall therefore not be construed as a commitment on the part of HMS Networks and is subject to change without notice. HMS Networks makes no commitment to update or keep current the information in this document.

The data, examples and illustrations found in this document are included for illustrative purposes and are only intended to help improve understanding of the functionality and handling of the product. In view of the wide range of possible applications of the product, and because of the many variables and requirements associated with any particular implementation, HMS Networks cannot assume responsibility or liability for actual use based on the data, examples or illustrations included in this document nor for any damages incurred during installation of the product. Those responsible for the use of the product must acquire sufficient knowledge in order to ensure that the product is used correctly in their specific application and that the application meets all performance and safety requirements including any applicable laws, regulations, codes and standards. Further, HMS Networks will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features or functional side effects found outside the documented scope of the product. The effects caused by any direct or indirect use of such aspects of the product are undefined and may include e.g. compatibility issues and stability issues.

# 1 Preparation

### 1.1 About This Document

This document describes how to install Anybus Wireless Bolt and set up a basic configuration.

For additional documentation, configuration examples, FAQs, troubleshooting guides and technical support, please visit <a href="http://www.anybus.com/support">www.anybus.com/support</a>.

### 1.2 Document Conventions

The following conventions are used to indicate safety information and other important content in this document:



#### WARNING

Instruction that must be followed to avoid a risk of death or serious injury.



#### Caution

Instruction that must be followed to avoid a risk of personal injury.

Instruction that must be followed to avoid a risk of reduced functionality and/or damage to the equipment, or to avoid a network security risk.



Additional information which may facilitate installation and/or operation.

### 1.3 Trademarks

Anybus<sup>∗</sup> is a registered trademark and Wireless Bolt<sup>™</sup> is a trademark of HMS Industrial Networks AB. All other trademarks mentioned in this document are the property of their respective holders.

### 1.4 Intended Use

This equipment is intended to provide wireless communication over WLAN and Bluetooth<sup>\*</sup> to wired networks.

Typical applications for this equipment:

- Adding wireless cloud connectivity to industrial devices
- · Accessing devices from a laptop, smartphone or tablet
- Ethernet cable replacement between devices

#### Note:

Bluetooth PAN (Personal Area Network) may not work with some devices due to different implementations of Bluetooth by different manufacturers.

WLAN 5 GHz cannot be used at the same time as WLAN 2.4 GHz or Bluetooth.

# 2 Installation

### 2.1 General Safety Instructions

#### Caution

This equipment emits RF energy in the ISM (Industrial, Scientific, Medical) band. Make sure that all medical devices used in proximity to this equipment meet appropriate susceptibility specifications for this type of RF energy.



#### Caution

Minimum temperature rating of the cable to be connected to the field wiring terminals, 90  $^{\circ}\mathrm{C}.$ 



#### Caution

Use copper wire only for field wiring terminals.

This equipment is recommended for use in both industrial and domestic environments. For industrial environments it is mandatory to use the functional earth connection to comply with immunity requirements. For domestic environments the functional earth must be used if a shielded Ethernet cable is used, in order to meet emission requirements.

This equipment contains parts that can be damaged by electrostatic discharge (ESD). Use ESD prevention measures to avoid damage.

### 2.2 General Information

Make sure that you have all the necessary information about the capabilities and restrictions of your local network environment before installation.

For optimal reception, wireless devices require a zone between them clear of objects that could otherwise obstruct or reflect the signal. A minimum distance of 50 cm between the devices should also be observed to avoid interference.

The characteristics of the antenna should also be considered when choosing the placement and orientation of the unit. See the Anybus Wireless Bolt User Manual for more information.

### 2.3 Mechanical Installation

The device is intended to be mounted on top of a machine or cabinet through an M50 (50.5 mm) hole using the included sealing ring and nut.

The top mounting surface (in contact with the sealing) must be flat with a finish equivalent to Ra 3.2 or finer and cleaned and free from oils and greases.

Tightening torque: 5 Nm ±10 %

Make sure that the sealing ring is correctly placed in the circular groove in the top part of the housing before tightening the nut.

Always hold the BOTTOM part of the unit when untightening the nut, not the top part (the cap).



All measurements are in mm.



Note the location of the **RESET** button when the connector is attached to the Wireless Bolt. Pin 1 will be the pin closest to the button.

18-pin Connector				
Pin	Name	Description		
1	VIN	Power 9–30 VDC		
2	GND	Power Ground		
3	DI	Digital input (9–30 VDC)		
4	DI_GND	Digital input ground		
5	ETN_RD+	Ethernet receive + (white/orange)		
6	ETN_RD-	Ethernet receive - (orange)		
7	ETN_TD-	Ethernet transmit - (green)		
8	ETN_TD+	Ethernet transmit + (white/green)		
9	RS485_B	RS-485 B Line		
10	FF/Shield	Ethernet: Functional Earth		
10	1 E/ Shield	Serial: Functional Earth and Shield		
11	RS232_TXD	RS-232 Transmit		
12	RS485_A/RS232_RXD	RS-485 A Line / RS-232 Receive		
13		RS-232 Request To Send		
	K5232_K15	Not supported for Wireless Bolt.		
14		RS-232 Clear To Send		
	K3232_C13	Not supported for Wireless Bolt.		
15	ISO_5V	Isolated 5 V for serial interface		
16	ISO_GND	Isolated Ground for serial interface		
17	CAN_L	CAN Low		
18	CAN_H	CAN High		

- If using a shielded Ethernet cable the shield must be unconnected.
- RS-232 and RS-485 cannot be used at the same time.
- Use termination for RS-485 and CAN when required.

### 2.5 Ethernet Cabling

To make an Ethernet connector cable for Anybus Wireless Bolt:



- 1. Cut off one of the connectors on a standard Cat5e or Cat6 Ethernet cable.
- Strip off about 40 mm (1½ inch) of the cable jacket and untwist the orange, orange/white, green and green/white wires. The other wires will not be used.
- 3. Strip off about 7 mm (¼ inch) of the isolation on each wire.
- Push the pin spring release next to each socket on the connector and insert the correct wire end according to 18-pin Connector, p. 8.

Connect the wires from the power supply to the connector in the same way as the Ethernet wiring. Make sure that polarity is not reversed.

#### **RJ-45 Adapter**

An Ethernet adapter with an RJ45 female connector can be ordered as an accessory. Please contact your sales representative for more information.

### 2.6 Digital Input

The digital input can be used to control roaming between Bluetooth access points (NAP). For more information, refer to the AT Reference Guide at <a href="http://www.anybus.com/support">www.anybus.com/support</a>.

If voltage is applied to the digital input for more that 10 seconds the unit will be reset to factory defaults.

### 2.7 RESET Button



The **RESET** button is located on the bottom of the unit.

When the unit is powered on, press and hold **RESET** for >10 seconds and then release it to reset to the factory default settings.

#### **Recovery Mode**

I

If the web interface cannot be accessed, the unit can be reset by starting in *Recovery Mode* and reinstalling the firmware using Anybus Firmware Manager II, which can be downloaded from www.anybus.com/support.

To enter Recovery Mode, press and hold **RESET** during startup.

Firmware updates should normally be carried out through the web interface. Recovery Mode should only be used if the unit is unresponsive and the web interface cannot be accessed.

# 3 Configuration

Anybus Wireless Bolt is configured via a web interface. Parameters can be set individually or using pre-configured **Easy Config** modes.

Advanced configuration can be carried out by issuing AT commands via the web interface or over a Telnet or RAW TCP connection to port 8080.

### 3.1 Web Interface

The web interface is accessed by pointing a web browser to the IP address of the unit. The default address is **192.168.0.99**.

System Overview	IP	
Easy Config	IP Assignment	Static
Network Settings	IP Address Subnet Mask	192.168.0.99 255.255.255.0
WLAN Settings	Default Gateway	192.168.0.99
Bluetooth Settings	Internal DHCP Server	Disabled
Rivetooth LE Settings	LAN	
Firmware Update	Connection MAC Address	Connected 00-30-11-19-43-2C
AT Commands	WIAN	
System Settings	Status	Qn
Help	Operating Mode	Client
	Connection	Connected
Save and Reboot	World Mode (1-11,36-140)	Enabled
Cancel All Changes	Channel Channel Bands	Auto 2.4 GHz & 5 GHz

The configuration settings are described in detail in the User Manual.

### 3.2 Easy Config Modes

By default Wireless Bolt starts in Easy Config mode 4, when:

- the Ethernet connection is not used
- connected to power
- factory default settings are used

EC	Role	Description
1	Bluetooth PANU	Configure as Bluetooth client and scan for another client
_		(PANU to PANU).
2	-	Reset configuration to factory defaults.
3	_	Reset IP settings to factory defaults.
4		Wait for automatic configuration.
	Client	Configure units in mode 4 as clients.
		When mode 4 is used with mode 1, 6 or 7, Serial
		Settings TCP Mode Client is activated automatically.
5	WLAN AP	Configure units in mode 4 as clients.
6	Bluetooth NAP	Restart as access point and connect clients.
7	WLAN AP	Configure units in mode 4 as clients.
		Restart as access point and connect clients.
8	Bluetooth NAP	Apply PROFINET optimization to all units.
		Configure as Bluetooth client and scan for another client
9	Bluetooth PANU	(PANU to PANU).
		Apply PROFINET optimization to both units.
10	(any)	Apply PROFINET optimization and restart.
11	(any)	Enable PROFIsafe mode.

The Easy Config modes are also described when selected in the web interface.

### 3.3 I/O-Data Cycle Time

Based on recommendations from industrial equipment suppliers, such as Rockwell and Siemens, it is recommended to use the following minimum I/Odata cycle times for PROFINET and EtherNet/IP networks:

- Wireless link Point-to-Point with Bluetooth PANU-PANU or Wi-Fi Access Point to Station: 32 ms
- Wireless link with Access Point and up to 4 wireless clients/stations, Bluetooth or Wi-Fi: 64 ms

#### 3.4 Factory Restore

Any one of these actions will restore the factory default settings:

- Clicking on Factory Restore on the System Settings page
- Executing Easy Config Mode 2
- Issuing the AT command AT&F and then restarting the unit
- Holding RESET pressed for >10 seconds and then releasing it
- Applying voltage to the digital input for >10 seconds

#### Default Network Settings

IP Assignment	Static
IP Address	192.168.0.99
Subnet Mask	255.255.255.0
Default Gateway	192.168.0.99
Internal DHCP	Disabled
Server	
DHCP Interfaces	All

#### **Default WLAN Settings**

Operating Mode	Client
Channel Bands	2.4 GHz & 5 GHz
Authentication	WPA/WPA2-PSK
Mode	
Channel	Auto
Bridge Mode	Layer 3 IP forward

#### **Default Bluetooth Settings**

Operating Mode	PANU (Client)
Local Name	[generated from MAC address]
Connectable	No
Discoverable	No
Security Mode	Just works
Bluetooth LE	Operating Mode: Disabled
	Connectable: No
	Discoverable: No

3.5 Configuration Examples

#### 3.5.1 Ethernet Bridge via WLAN or Bluetooth<sup>®</sup> (Easy Config)



This example describes how to connect two Ethernet network segments via WLAN or Bluetooth using Easy Config.

1. In the web interface of unit 1, activate **Easy Config Mode 4**. This unit will now be discoverable and open for automatic configuration.

	Select Easy Config Mode	
	4- Await automatic discovery and configuration	-
Easy Config	4 - Await automatic discovery and configuration	

 In the web interface of unit 2, activate Easy Config Mode 5 for WLAN or 6 for Bluetooth. Unit 2 will now discover and configure unit 1 as a client and configure itself as an access point.

	Select Easy Config Mode	
	5- Configure as WLAN access point and scan for clients	-
Easy Config	5 - Configure as WLAN access point and scan for clients	

Unit 1 will be assigned the first free IP address in the same Ethernet subnet as unit 2.

#### Adding More Devices

Up to 6 additional clients can be added by repeating the procedure. Each new client will be assigned the next free IP address in the current subnet.

# 4 Technical Data

For complete technical specifications and regulatory compliance information please visit <u>www.anybus.com/support</u>.

Order code	AWB2000	AWB2001	
Color	Black	White top and black base	
Wired interface type	Ethernet		
Connector	Included plug connector		
Antenna	Internal dual-band 2.4 GHz and 5 GHz antenna		
Maximum range	100 m (WLAN and Bluetooth)		
Operating temperature	Shadow: -40 to +65 °C Direct sunlight: -40 to +45 °C	Shadow: -40 to +65 °C Direct sunlight: -40 to +65 °C	
Storage temperature	-40 to +85 °C		
Humidity	EN 600068-2-78: Damp heat, +40°C, 93% humidity for 4 days.		
Vibration	See datasheet		
Dimensions	Height: 75 mm (95 mm incl. connector, 41 mm outside) Diameter: 68 mm		
Weight	81 g		
Housing material	Plastic (see datasheet for details)		
Protection class	Top (outside of host): IP66 / IP67 / UL Type 4X Base (inside of host): IP21		
Mounting	M50 screw and nut (50.5 mm hole needed)		
Power supply	9–30 VDC (-5 % +20 %) Cranking 12 V (ISO 7637-2:2011 pulse 4) Reverse polarity protection		
Power consumption	0.7 W idle, 1.7 W max.		

### 4.1 Hardware Specifications

© 2021 HMS Industrial Networks Box 4126 300 04 Halmstad, Sweden

info@hms.se